



Models VLS2.30 & VLS3.50

Safety, Installation, Operation,
and Basic Maintenance Manual

System Serial Number: _____

(Located on the back of the machine)

Laser Tube Serial Number(s):

Universal Laser Systems, Inc.

16008 North 81st Street
Scottsdale, AZ 85260 USA
Technical Support Department
Phone: 480-609-0297
Fax: 480-609-1203

Web Based Email Support: www.ulsinc.com/VersaLASER/

March 2008



Notice

This publication and its contents are proprietary to Universal Laser Systems, Inc. (ULS), and are intended solely for the contractual use of ULS, Inc. customers.

While reasonable efforts have been made to assure the accuracy of this manual, ULS shall not be liable for errors contained herein or for incidental or consequential damage in connection with the furnishing, performance, or use of this material. ULS reserves the right to revise this manual and make changes from time to time without obligation by ULS to notify any person of such revision or changes.

ULS does not assume any liability arising out of the application or use of any products, circuits, or software described herein. Neither does it convey a license under its patent rights nor the patent rights of others.

This publication and its contents may not be reproduced, copied, transmitted, or distributed in any form, or by any means, radio, electronic, mechanical, photocopying, scanning, facsimile, or otherwise, or for any other purpose, without the prior written permission of ULS.

ULS provides no warranties whatsoever on any software used in connection with a ULS Laser Engraving System, express or implied. Neither does it guarantee software compatibility with any off-the-shelf software package or any software program that has not been written by ULS.

Intended use of this system must be followed within the guidelines of this manual. In no event will ULS be liable for any damages caused, in whole or in part, by customer, or for any economic loss, physical injury, lost revenue, lost profits, lost savings or other indirect, incidental, special or consequential damages incurred by any person, even if ULS has been advised of the possibility of such damages or claims.

WARNING: UNIVERSAL LASER SYSTEMS PRODUCTS ARE NOT DESIGNED, TESTED, INTENDED OR AUTHORIZED FOR USE IN ANY MEDICAL APPLICATIONS, SURGICAL APPLICATIONS, MEDICAL DEVICE MANUFACTURING, OR ANY SIMILAR PROCEDURE OR PROCESS REQUIRING APPROVAL, TESTING, OR CERTIFICATION BY THE UNITED STATES FOOD AND DRUG ADMINISTRATION OR OTHER SIMILAR GOVERNMENTAL ENTITIES. SHOULD THE BUYER USE UNIVERSAL LASER SYSTEMS PRODUCTS FOR ANY SUCH UNINTENDED OR UNAUTHORIZED APPLICATION, ALL WARRANTIES REGARDING THE UNIVERSAL LASER SYSTEMS PRODUCTS SHALL BE NULL AND VOID. FURTHER, THE BUYER SHALL HAVE NO REMEDY AGAINST UNIVERSAL LASER SYSTEMS AND ITS OFFICERS, EMPLOYEES, SUBSIDIARIES, AFFILIATES AND DISTRIBUTORS FOR, AND THE BUYER SHALL INDEMNIFY AND HOLD THOSE PARTIES HARMLESS AGAINST, ANY AND ALL CLAIMS, COSTS, DAMAGES, EXPENSES AND REASONABLE ATTORNEY FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM ASSOCIATED WITH SUCH UNINTENDED OR UNAUTHORIZED USE, INCLUDING BUT NOT LIMITED TO ANY CLAIM BASED ON WARRANTY (EXPRESS OR IMPLIED), CONTRACT, TORT (INCLUDING ACTIVE, PASSIVE, OR IMPUTED NEGLIGENCE), STRICT LIABILITY, PATENT OR COPYRIGHT INFRINGEMENT OR MISAPPROPRIATION OF INTELLECTUAL PROPERTY.

HP is a registered trademark of Hewlett-Packard Corporation.

Windows is a registered trademark of Microsoft Corporation.

Macintosh is a registered trademark of Apple Computer Corporation.

PostScript, Photoshop, and Streamline are registered trademarks of Adobe Systems Inc.

CorelDRAW is a registered trademark of Corel Corporation.

AutoCAD is a registered trademark of AutoDesk Inc.

ULS Platforms are protected under one or more of U.S. patents 5,661,746; 5,754,575; 5,867,517; 5,881,087; 5,894,493; 5,901,167; 5,982,803; 6,181,719; 6,313,433; 6,342,687; 6,423,925; 6,424,670; 6,983,001; D517,474; 7,060,934. Other U.S. and International patents pending.

**© Universal Laser Systems Inc., 2007
All Rights Reserved**

Introduction

All of us at Universal Laser Systems, Inc. (ULS) would like to thank you for your purchase. Since 1988, the staff at ULS has been dedicated to total customer satisfaction. When you buy Universal you get more than a money making product, you get a team of talented, experienced, and enthusiastic people who are focused on your satisfaction. Our commitment is to help you be successful right now and in the future.

To begin with, we highly recommend that this entire manual be read before attempting to use the device. The manual includes important information about safety, assembly, use, and basic maintenance.

How To Get Help

Before contacting our Technical Support Department, make sure that you have read this entire manual as well as any other accompanying manuals included with your laser system.

Step 1:

Try to recreate the problem and write down the circumstances in which the problem occurred. Try to recall if the problem began all of a sudden, worsened over time, or began after you performed any recent maintenance. Also be prepared to describe all pertinent information about the computer being used such as graphics software, Universal Control Panel (UCP) software version, computer operating system and computer type, configuration, and accessories.

Step 2:

Make sure that you have the system serial number available. The serial number tag is located on the back of the machine, next to the exhaust port. We may not be able to assist you without this number.

Step 3:

Contact your local VersaLASER reseller. If possible, call from a telephone that is close to the VersaLASER so that it can be operated while speaking on the telephone.

Step 4:

If your local VersaLASER reseller cannot assist you and you would like to use our **FREE**, email based support system, log on to our website: www.ulsinc.com/versalaser/. Click on the "Contact Us" link, then click on the "Technical Support Request" link and follow the instructions.

Step 5:

If you are unable to obtain Internet access, you may contact our Technical Support Department at:

Universal Laser Systems, Inc.

Technical Support Department

16008 North 81st Street

Scottsdale, AZ 85260

Phone: 480-609-0297

Fax: 480-609-1203

M-F 8am – 5pm Arizona Time

support@ulsinc.com

Specifications

System Operating Environment Requirements (user provided)

	Models	
	VLS2.30	VLS3.50
Operating Environment	Well-ventilated office (recommended) or clean, light-duty manufacturing area	
Operating Temperature	50°F (10°C) to 95°F (35° C) capable 73°F (22°C) to 77°F (25° C) for best performance	
Storage Temperature	50°F (10°C) to 95°F (35° C)	
Operating Humidity	Non-condensing	
Electrical Power	110/230 VAC, 10/5A, Grounded	110/230 VAC, 10/5A, Grounded
Particulate/Odor Outside Ventilated Exhaust System	High-pressure vacuum blower capable of 150 CFM (cubic feet per minute) @ 6 inches static pressure (255m3/hr at 1.5kPa)	
Computer Requirement	Windows XP or Windows Vista (32-bit version only) Available USB 2.0 High Speed port	
Software Requirement	Any Windows based Graphics or CAD application	

System Specifications

Laser Safety	CO2 Laser, Interlocked Safety Enclosure = Class I Red Diode Pointer = Class IIIa	
Laser Source	10, 25 or 30 watt CO2 Laser	10, 25, 30,40, or 50 watt CO2 Laser
Cooling	Air Cooled	
Work Area	16" x 12" (406.4 x 304.8 mm)	24" x 12" (609.6 x 304.8 mm)
Printer Driver	Windows XP or Windows Vista (only)	
Hardware Interface	USB 2.0 High Speed port	
Dimensions	26"Wide x 25" Deep x 14"Height (660.4mm x 635mm x 355.6)	34"Wide x 25" Deep x 14"Height (863.6mm x 635mm x 355.6)
System Weight	System = 85 lbs. (38 kg)	System = 100–106 lbs. (45-48 kg)
Laser Cartridge Weight	10 Watt = 13 lbs (6kg) 25/30 Watt = 20 lbs (9 kg) 40 Watt = 23 lbs (10 kg) 50 Watt = 26 lbs (12 kg)	
Available Options	Cart, Integrated Air Cleaner, Rotary Fixture, Air Assist, Compressed Air, Cutting Table, Focus Lens Kits	

Specifications subject to change without notice

Table of Contents

Section 1 – Safety

Description of Appropriate Use	1-1
General Safety	1-1
Laser Safety	1-2
Safety Labels	1-2
EU Compliance (CE).....	1-5
FCC Compliance.....	1-6
Recycling.....	1-6

Section 2 – Installation

Establishing a Proper Operating Environment.....	2-1
Extracting Fumes and Particulates	2-1
Providing a Suitable Electrical Power Source.....	2-3
Software Installation and Operating System Requirements	2-3
Computer Requirements	2-3
The Software Installation CD-ROM	2-5
Recommended Software Programs	2-6
Configuring Your Graphics Software.....	2-7
Unpacking and Assembling the VersaLASER	2-11
Finalizing the Connections.....	2-12

Section 3 – Running Your First Job

Step 1 – Creating Your Artwork	3-1
Step 2 – Printing Your Artwork.....	3-1
Step 3 – Powering On the VersaLASER.....	3-2
Step 4 – Loading and Positioning Your Material.....	3-2
Step 5 – Running Your Job.....	3-2
Step 6 – Powering Off the VersaLASER.....	3-2

Section 4 – Operation

How it Works	4-1
The VersaLASER Keypad	4-1
The Universal Control Panel (UCP)	4-2
Printer Driver Controls.....	4-4
Manual Focus.....	4-5

Section 5 – Basic System Maintenance

Safety	5-1
Cleaning and Maintenance Supplies	5-1
Optics	5-2
Optics Handling Guidelines	5-2
Optics Cleaning Procedure.....	5-2
Accessing the Optics	5-2
#2 Mirror	5-3
#3 Mirror and Focus Lens.....	5-3
Beam Window.....	5-4
The Motion System	5-4
The Main Enclosure	5-5
Adjustments and Lubrication.....	5-5
Interlock Safety Check	5-5
Fuse Replacement.....	5-5
Cooling Fan Filters	5-6
Maintenance Schedule.....	5-6

Section 6 – Accessories

Cylindrical Object Rotary Accessory.....	6-1
Vector Cutting Accessory.....	6-6
Integrated Cart	6-8
Computer Controlled Air Cleaner / Cart	6-8
Computer Controlled Compressed Air Unit.....	6-11
Air Assist Cone.....	6-12
Air Assist Back Sweep	6-14

Safety

Description of Appropriate Use

This device is designed for laser cutting and etching of the materials listed in the VersaLASER printer driver. Materials to be processed must fit completely inside the system for proper operation. Use of the equipment in a manner other than that described in this manual may result in injury to yourself and others and may cause severe damage to the equipment and your facility.



Notice: This device is not designed, tested, intended or authorized for use in any medical applications, surgical applications, medical device manufacturing, or any similar procedure or process requiring approval, testing, or certification by the United States Food and Drug Administration or other similar governmental entities. Please see the Notice herein for further information regarding such uses.

General Safety

- **EXPOSURE TO THE LASER BEAM MAY CAUSE PHYSICAL BURNS AND CAN CAUSE SEVERE EYE DAMAGE.** Proper use and care of this system are essential to safe operation.



- **NEVER OPERATE THE LASER SYSTEM WITHOUT CONSTANT SUPERVISION OF THE CUTTING AND ETCHING PROCESS.** Exposure to the laser beam may cause ignition of combustible materials and start a fire. A properly maintained fire extinguisher should be kept on hand at all times.

- **NEVER LEAVE MATERIALS IN THE LASER SYSTEM AFTER LASER PROCESSING HAS FINISHED.** Materials may ignite after laser processing has finished. Thoroughly inspect the interior of the laser system and remove any particulate materials before leaving your workstation. A properly maintained fire extinguisher should be kept on hand at all times.



- **A PROPERLY CONFIGURED, INSTALLED, MAINTAINED, AND OPERATING PARTICULATE/FUME EXHAUST SYSTEM IS MANDATORY WHEN OPERATING THE LASER SYSTEM.** Fumes and smoke from the etching process must be extracted from the laser system and either filtered through the Computer Controlled Air Cleaner (CCAC) (an optional accessory) or exhausted outside through a user supplied exhaust system.



- **SOME MATERIALS, DURING AND AFTER LASER PROCESSING, MAY PRODUCE TOXIC FUMES.** We suggest that you obtain the Material Safety Data Sheet (MSDS) from the materials manufacturer. The MSDS discloses all of the hazards when handling or processing that material. Some materials continue emitting fumes for several minutes after laser processing and may pose a health hazard.


Avoid using this device in small, enclosed, or non-ventilated areas.

- **SOME MATERIALS, DURING AND AFTER LASER PROCESSING, MAY PRODUCE CORROSIVE FUMES.** **DISCONTINUE** processing any material that produces signs of chemical deterioration in the laser system such as rust, metal etching or pitting, peeling paint, etc. Damage to the laser system from corrosive materials is **NOT** covered under warranty.



- **CARE SHOULD BE TAKEN WHEN MOVING OR LIFTING THIS DEVICE.** Obtain assistance from 1 or 2 additional people when lifting or carrying (secure motion system and access door). Severe bodily injury may occur if improper lifting techniques are applied or the system is dropped.

- **DANGEROUS VOLTAGES ARE PRESENT WITHIN THE ELECTRONICS AND LASER ENCLOSURES OF THIS SYSTEM.** Although access to these areas is not necessary during normal use, if it becomes necessary to open one of these enclosures for service reasons, please remember to disconnect the power cord from your electrical supply.



- **THE POWER SUPPLY CORD IS THE MAINS DISCONNECT DEVICE; THE EQUIPMENT SHOULD BE LOCATED CLOSE TO AN EASILY ACCESSIBLE WALL SOCKET OUTLET.** To disconnect the equipment from the supply mains, the power cord shall be unplugged from the wall outlet or main power inlet (appliance coupler) of the unit.

- **THIS DEVICE IS SPECIFICALLY DESIGNED TO COMPLY WITH CDRH PERFORMANCE REQUIREMENTS UNDER 21 CFR 1040.10 AND 1040.11.** CDRH is the Center for the Devices of Radiological Health division of the Food and Drug Administration (FDA) in the USA. It also complies with CE (European Community) safety regulations. No guarantees of suitability or safety are provided for any use other than those specified by Universal Laser Systems, Inc.

Laser Safety

The device contains a sealed carbon dioxide (CO₂) laser in a Class I enclosure that produces intense invisible and visible laser radiation at a wavelength of 10.6 microns in the infrared spectrum. For your protection, this enclosure is designed to completely contain the CO₂ laser beam.



CAUTION – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

- The intense light that appears during the etching or cutting process is the product of material combustion or vaporization. **DO NOT STARE AT THIS LIGHT FOR EXTENDED PERIODS OR ATTEMPT TO VIEW IT WITH OPTICAL INSTRUMENTS.**
- This device contains a visible Red Dot Pointer (Class IIIa, 5mw maximum output, 630-680 nm). **DO NOT STARE AT THIS RED LIGHT FOR EXTENDED PERIODS OR ATTEMPT TO VIEW IT WITH OPTICAL INSTRUMENTS.**
- The user access door of this device is safety interlocked and will disable the CO₂ laser beam when the access door is opened. The Red Dot Pointer is **NOT** safety interlocked and is automatically activated when the user access door is open.
- **DO NOT OPERATE THE LASER SYSTEM IF ITS SAFETY FEATURES HAVE BEEN MODIFIED, DISABLED OR REMOVED.** This may lead to exposure to invisible and visible CO₂ laser radiation which may cause permanent blindness and/or severe burns to the skin.

Safety Labels

CDRH and CE regulations require that all laser manufacturers affix warning labels in specific locations throughout the equipment. The following warning labels are placed on the laser system for your safety. **DO NOT** remove them for any reason. If the labels become damaged or are removed for any reason, **DO NOT OPERATE** the laser system and immediately contact Universal Laser Systems, Inc. for free replacements. Labels are **NOT** to scale.



SAFETY

THIS EQUIPMENT CONFORMS
TO PROVISIONS OF
US 21 CFR 1040.10
AND 1040.11

221-0015-0

CAUTION

CLASS 4 INVISIBLE LASER RADIATION
WHEN OPEN AND INTERLOCK FAILED OR
DEFEATED AVOID EYE OR SKIN EXPOSURE
TO DIRECT OR SCATTERED RADIATION

221-0016-0

CAUTION

CLASS 4 INVISIBLE LASER
RADIATION WHEN OPEN
AVOID EYE OR SKIN EXPOSURE TO
DIRECT OR SCATTERED RADIATION

221-0017-0

AVOID EXPOSURE

INVISIBLE LASER RADIATION IS
EMITTED FROM THIS APERTURE

221-0018-0



WARNING
TO AVOID RISK OF ELECTRIC SHOCK
ALWAYS DISCONNECT POWER CORD
BEFORE REMOVING THIS COVER

221-0020-0

INPUT POWER:
110 VAC; 50/60 Hz; 10 A

221-0022-0

THIS LASER MANUFACTURED BY
UNIVERSAL LASER SYSTEMS
16008 N. 81ST ST
SCOTTSDALE, AZ 85260 USA

IS DESIGNED FOR USE ONLY AS A COMPONENT IN A
ULS LASER SYSTEM. THIS LASER IS A CLASS 4 DEVICE AND
DOES NOT COMPLY WITH U.S. CODE 21 CFR SUBCHAPTER J
OR EUROPEAN STANDARD EN 60825-1:1994.

THIS LASER PRODUCT IS MANUFACTURED UNDER ONE
OR MORE OF U.S. PATENTS 5,661,746; 5,754,575; 5,867,517;
5,881,087; 5,894,493; 5,901,167; 5,982,803; 6,181,719; 6,983,001
OTHER U.S. AND INTERNATIONAL PATENTS PENDING.

221-0031-0



CAUTION LASER RADIATION
AVOID DIRECT EYE EXPOSURE
CLASS 3R LASER PRODUCT

LASER DIODE
WAVELENGTH: 630-680 nm
MAX. OUTPUT: 5 mW

221-0033-0

DANGER



LASER RADIATION - AVOID
DIRECT EYE EXPOSURE

LASER DIODE
WAVELENGTH: 630-680 nm
MAX. OUTPUT: 5 mW
CLASS 3R LASER PRODUCT

221-0034-0

INPUT POWER:
230 VAC; 50/60 Hz; 5 A

221-0036-0

SAFETY

THIS PRODUCT IS MANUFACTURED UNDER ONE
OR MORE OF U.S. PATENTS 5,051,558; 5,661,746; 5,754,575;
5,867,517; 5,881,087; 5,894,493; 5,901,167; 5,982,803; 6,181,719;
6,313,433; 6,342,687; 6,423,925; 6,424,670; 6,983,001;
D517,474; 7,060,934
OTHER U.S. AND INTERNATIONAL PATENTS PENDING.

221-0065-0



WARNING

Do **NOT** use in medical or surgical applications or to manufacture medical devices. See the Safety, Installation, Operation, and Basic Maintenance Manual, or the OEM Laser Integration Manual for further information.

221-0081-0





WARNING




THIS SYSTEM IS DESIGNED FOR
USE WITH INERT AND
NON-OXIDIZING GASES ONLY
(i.e. DRY CLEAN AIR, CARBON
DIOXIDE, HELIUM, NITROGEN).
CONNECTING FLAMMABLE OR
OXIDIZING GASES TO THIS
SYSTEM CREATES A SERIOUS
SAFETY AND/OR FIRE HAZARD.
DO NOT CONNECT ANY GAS
SOURCES EXCEEDING 75 PSI
(5 ATM) PRESSURE.
UNIVERSAL LASER SYSTEMS
ASSUMES NO RESPONSIBILITY
ARISING FROM THE IMPROPER
USE OF THIS SYSTEM.

221-0037-0

SAFETY



SAFETY



EU Declaration of Conformity

UNIVERSAL
LASER SYSTEMS INC.

Product Identification: VLS2.30 and VLS3.50
Laser Engraving and Cutting Systems

Manufacturer:
Universal Laser Systems, Inc.
16008 N. 81st St.
Scottsdale, AZ 85260
USA

European Office:
Universal Laser Systems GmbH
Lerchenfelder Guertel 43
A-1160 Vienna/Austria

The manufacturer hereby declares that the equipment specified below is in conformity with the following directives:

89/336/EEC	(EMC Directive)
73/23/EEC	(Low Voltage Directive)
98/37/EEC	(Machinery Directive)
2002/95/EEC	(ROHS Directive)
2002/96/ECC	(WEEE Directive)

based on the standards listed.

Standards Used:

Safety:

EN 60950: 2002
EN 60825-1: 2002 (Class 3R)

EMC:

EN 55024 1998 (Class A)
EN 55022: 2003 (Class A)
EN 61000-3-2: 2001 (class A)
EN 61000-3-3: 2002
EN 61000-4-2: 2001 (4kV CD, 8kV AD)
EN 61000-4-3: 2003 (3 or 10 V/m)
EN 61000-4-4: 2002 (1 or 2 kV power line)
EN 61000-4-5: 2001 (class 3)
EN 61000-4-6: (3 or 10Vrms)
EN 61000-4-8
EN 61000-4-11

Note: This is not a declaration of conformity. The importer of this equipment supplies the declaration of conformity.

Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

FCC Compliance

This ULS laser system has been tested and found to comply with Federal Communication Commission (FCC) directives regarding Electromagnetic Compatibility (EMC). In accordance with these directives ULS is required to provide the following information to its customers.

FCC Compliance Statement and Warnings

This device complied with FCC Rules Part 15. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device as set forth in Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his or her own expense.

Users should be aware that changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate the equipment.

This equipment has been type tested and found to comply with the limits for a Computing Device per FCC part 15, using shielded cables. Shielded cables must be used in order to insure compliance with FCC regulations.

Recycling



By placing the above symbol on our products and accessories Universal Laser Systems is indicating that we are committed to helping reduce the amount of waste electronics ending up in municipal landfills. Therefore Universal Laser Systems urges consumers to recycle this product and its accessories. Universal Laser Systems is equipped to recycle any of its electronic products and accessories and will assist our customers with their recycling options. To arrange for recycling of your ULS product or accessory, please contact Universal Laser Systems for more information.

SAFETY

Installation

In this section we will step you through site preparation, computer and software setup, and unpacking and assembling the VersaLASER. Follow the instructions in the order shown:

1. Establishing a Proper Operating Environment
2. Extracting Fumes and Particulates
3. Providing a Suitable Electrical Power Source
4. Software Installation and Operating System Requirements
5. Unpacking and Assembling the VersaLASER
6. Finalizing the Connections



It is essential to follow the step-by-step installation procedure as described in this section. Improper installation of the laser system may cause undesired results in the engraving process or may even damage your laser system.

1. Establishing a Proper Operating Environment

Environment (user supplied)

- The device **MUST** be installed in an office-type or light duty manufacturing environment. Airborne pollutants can damage the device. Keep the device isolated from any sandblasting, sanding or machining equipment or any other machinery that produces airborne particles. Also, do not operate or store this device near sources of water, saltwater, or oil vapor.
- For best results, we recommend operating this air-cooled device in the ambient temperature range of 73°F (22°C) to 77°F (25° C).
- Avoid storing the device outside the temperature range of 50°F (10°C) to 95°F (35° C) as excessively cold or hot temperatures can damage the laser cartridge or reduce its lifetime.
- Ambient humidity levels must be non-condensing.
- A suitable working surface for all material processing.

2. Extracting Fumes and Particulates

Exhaust System (user supplied)

Fumes, smoke, and particulates are a byproduct of the cutting and marking of materials in the VersaLASER and **MUST** be extracted (vacuumed) from the VersaLASER. You may choose to either exhaust them to the outside environment or filter them.

External Exhaust (most common): We recommend that you contact a local contractor to design and install an exhaust system that not only meets the minimum requirements of this device but also complies with local environmental laws.


- The exhaust system **MUST** be capable of supplying a minimum of 150 CFM (cubic feet per minute) of airflow while under a load of 6 inches of static pressure (254 m3/hr at 1.5kPa). **DO NOT** install forward incline, backward incline, in-line, or ventilator fans because these types of air handlers are inadequate and inappropriate for this type of installation. A high-pressure blower **MUST** be used to meet minimum airflow requirements.
- For personal safety and noise control reasons, we recommend that the blower be mounted **OUTSIDE** the building.

INSTALLATION

- Rigid tubing should be used for 90% of the distance traveled between the blower and the laser system. The tubing should be smooth walled and have as few 90 degree bends as possible.
- Install a gate to control airflow and to close off the exhaust from the outside environment when the laser is not in use. Place this gate within 5 – 10 feet from the laser system.
- Use a short piece of industrial grade, wire reinforced rubber tubing to connect the end of the gate to the laser system. This will provide mobility and will dampen blower vibrations.
- Have the blower electrically wired to a wall switch in the same room for easy ON/OFF control.

The following diagram shows a typical exhaust system layout. Use this as a guideline to proper exhaust system installation.

NOTE: Although this diagram just serves as an example, we recommend installation of the exhaust system by a local, licensed contractor to meet safety and local code requirements as well as being able to calculate the correct size blower required for your particular installation. Length of exhaust pipe, exhaust pipe diameter, number of 90-degree angles, and other restrictions must be calculated when determining the correct exhaust blower unit. Installing an undersized or oversized blower is not only unsafe, but it can also lead to premature and excessive wear and tear to the laser system as well as premature failure of the blower.



- 1) High Pressure Exhaust Blower
- 2) Weather-proof Cover
- 3) Rigid Ducting
- 4) Airflow Gate
- 5) Reducer
- 6) 3 inch Diameter, Industrial Grade Flexible Tubing
- 7) On/Off Switch
- 8) Computer (user supplied)

Filtration System: If you have chosen to purchase the optional Computer Controlled Air Cleaner (CCAC) accessory, exhausting to the outside environment is not required.

3. Providing a Suitable Electrical Power Source

Electrical (user supplied)

- The electrical power requirements can be found either in the “Specifications” table in the beginning of this manual or printed on the label next to the power inlet of the VersaLASER.
- The VersaLASER and VersaLASER accessories are equipped with standard IEC 60320 “computer style” power cord receptacles.
- **NEVER REMOVE THE GROUND (EARTH) LEAD TO THE ELECTRICAL CORD AND PLUG THE SYSTEM INTO THE NON-GROUNDED (NON-EARTHEDED) OULET.** Operating the device without the ground connection is very dangerous and can lead to a severe, if not fatal, electrical shock. It may also cause the device to exhibit unpredictable behavior.
- Noisy or unstable electricity as well as voltage spikes may cause interference and possible damage to the device’s electronics. If electrical power fluctuations, brown outs, or constant power outages are a problem in your area, an electrical power stabilizer, UPS (Uninterruptible Power Supply), or backup generator may be required.
- To prevent the overload of your electrical power circuit or to control an unstable or noisy electrical power source, it may be necessary to connect the device to a dedicated electrical circuit.
- The device is designed as a Class I, Group A, pluggable device. It is also designed for connection to IT power systems.



4. Software Installation and Operating System Requirements

Your computer is a critical component in the operation of the VersaLASER. In fact, you cannot power on the VersaLASER if your computer is not connected, powered on, running Windows, and running the Universal Control Panel software (UCP).

Only **ONE** VersaLASER per computer is allowed. You will need to purchase a separate computer for each VersaLASER you own. Also, the VersaLASER is **NOT** designed to be a network printer. **YOU MUST** operate the VersaLASER using the computer that is directly attached to it via the **PROVIDED**, 3 foot, USB cable. **USB cables longer than 3 feet may cause the VersaLASER to malfunction.**

A. Computer Requirements

PC Requirements (user supplied)

2.0 GHz processor	Mouse and keyboard
Windows XP Home, Professional Edition, or Windows Vista**. Macintosh computers not compatible with VersaLASER.	Available USB 2.0 High Speed compliant port
1 GB of RAM	Computer speakers
40 GB hard drive (15 GB free space)	600 DPI scanner (optical)
VGA monitor (minimum 1024 x 768 resolution)	Internet connection and email address (optional)
CD-ROM Drive/Burner	

**The VLS machine is compatible with a 32 bit Windows Vista version. See www.microsoft.com for the minimum computer requirements to run Windows Vista.

NOTE: Some computer motherboard manufacturers USB ports DO NOT comply with USB 2.0 High Speed standards. This may cause erratic behavior from the VersaLASER such as freezing and lock-ups.

Other USB peripheral devices that demand a large amount of computer processing power may slow down the operation and productivity of the VersaLASER. We recommended not using these devices while operating the VersaLASER.

NOTE: Laptop computers are known for having low powered USB ports. If using a laptop most likely you will need to use an external USB port hub, that has its own AC power adapter, and install it between the computer's USB port and the VersaLASER's USB port.



Optimizing Windows XP Performance


Windows XP, by default, displays many "visual effects" that slow down the computer by utilizing RAM and processor time. We recommend that you turn **OFF** these effects by right-clicking on the My Computer icon on your desktop, then click Properties and then click the Advanced tab. In the Performance section, click Settings, then click Adjust For Best Performance, and then click Apply.



Computer Power Management

Power management is a configuration setting in Windows XP that reduces the energy consumption of computers and monitor by shutting them down after a period of inactivity. However, since your computer is a critical component in the operation of the VersaLASER, you **MUST NEVER** allow your computer to go into the Standby or Hibernate mode.

 <ol style="list-style-type: none"> 1. To properly configure Power Management in your Windows XP computer, right-click on your desktop. 2. From the list of options, select "Properties". The "Display Properties" box will open. 	 <ol style="list-style-type: none"> 3. In Display Properties, select the Screen Saver tab. Set the Screen saver to "(None)". 4. Then in the box "Monitor power", Click the button "Power..."
---	---



5. Select the tab "Power Schemes".
6. For the Power Scheme in use, select "Never" for all the setting options: Turn off monitor, Turn off hard disks, System standby, and System hibernates.
7. Click "Apply", then "OK" on both open windows.

If you have further questions on how to configure or upgrade Windows XP, please contact Microsoft Corporation.


NOTE: Your chosen graphical software AND VersaLASER software MUST be installed and operational before operating the machine.

B. The Software Installation CD-ROM

The Software Installation CD-ROM can be found in a pocket on the inside of the back cover of this manual. In order to install the software you **NEED** to have administrative privileges on the user account that is currently logged on.




1. Insert the Software Installation CD-ROM into your PC's CD drive. It should automatically open the "ULS Engraver Software Setup" window. Read the instructions and then click the "Install" button.
 - a. If the window does not automatically open, you can open it from Windows Explorer through your CD drive. Double-click on the file *Setup.exe*. The software will automatically begin to load.



2. The installation process will begin indicated by a progress bar. Be patient. Loading the files can take a few minutes depending on your processor speed.



3. You will be prompted to select your model. Select the laser engraver you are installing on the computer then click on "Ok". The software will continue loading as indicated by a progress bar.
 - a. If the incorrect model is selected you will receive an error message later in the engraving process. Uninstall the printer driver and reinstall it by choosing the correct model.



4. When the installation process is finished the "Completing the ULS Engraver Software Setup Wizard" window will appear. If you would like to run the ULS Engraver Software after installation is complete, verify that the box has been marked. Click on the "Finish" button to complete installation. The window will automatically close. Remove the Software Installation CD-ROM. All the files required to operate your machine have been loaded onto your computer.

C. Recommended Software Programs

All software necessary to control the VersaLASER is included. However, the software necessary to create the artwork is **NOT** included. ULS recommends the following software for use with the VersaLASER:

- **Vector Graphics Programs**
CorelDRAW 12 or X3**
- **Bitmap / Scanning Software**
Adobe Photoshop (recommended) or Corel PHOTO-PAINT
- **Raster to Vector Conversion Software**
CorelTRACE
- **CAD Software**
AutoCAD or AutoCAD LT for Windows
- **FONTS**
Use True Type fonts **ONLY**. Do not use PostScript or bitmapped fonts.

Once you have installed your preferred software according to the manufactures instructions you will need to configure your graphics software according to our instructions.

****Most users purchase the CorelDRAW 12 or CorelDRAW X3 Graphics Suite package which contains all the software necessary to operate the VersaLASER to its fullest capability. Earlier versions of CorelDRAW have experienced problems with the XP operating system, which in turn, causes problems with the operation of the VersaLASER. As a result ULS recommends CorelDRAW 12 over earlier versions. Whether you decide to use CorelDRAW12 or a different graphics software package, it is critical that you fully understand how to use the software in order to successfully operate the VersaLASER. While ULS has made reasonable efforts to make the VersaLASER as compatible as possible with graphics and CAD software written for the Windows XP operating systems, ULS cannot guarantee complete compatibility with any software not manufactured by ULS.**

D. Configuring Your Graphics Software


After the VersaLASER software installation is completed, you must configure your graphics software to work correctly with the VersaLASER. The basic setup should include the following:

- Set the default page orientation to Landscape and page size to a width of 16 inches (406.4mm) (model VLS2.30) or 24 inches (609.6mm) (model VLS3.50) and height of 12 inches (304.8mm).
- Set the default line thickness to Hairline or the smallest available by the software (for vector output).
- Use only the color Black for fills for etching, Red outlines for cutting, and Blue outlines for scribing. We will discuss more about using your graphics software in Section 3 of this manual.


NOTE: Since most users use CorelDRAW 12 and X3, we have included the following specialized configuration instructions. Set the appropriate dimensions according to your VersaLASER table size.

CorelDRAW 12


Windows XP

1. Make sure that you have installed all Service Releases and software patches from Microsoft. For Windows XP, install Service Pack 2. If you are reading this document from the Software Installation CD-ROM, as a service to you, you can find the file on this CD. For the latest releases, check Microsoft's website, www.microsoft.com. Please contact Microsoft if you have any questions regarding these upgrades. ULS is not responsible for any problems as a result from the usage of these patches.
2. If you have not already done so, install CorelDraw on your computer, but do not open it yet.
3. It is important that your version of CorelDraw is updated with the latest patches and service releases. For the latest patches and updates go to CorelDraw's website, www.corel.com. Be sure to check for any updates from time to time to keep your version up to speed. Please contact CorelDraw if you have any questions regarding these upgrades. ULS is not responsible for any problems as a result from the usage of these patches.
4. The ULS Windows Printer Driver must be loaded before continuing. Please refer to Section 2-5 on the manual on how to install the driver. If you have already installed the printer driver, you will need to re-insert the Software Installation CD-ROM back into your CD drive at this time.
5. If the Software Installation CD-ROM autoruns cancel the installation process. Using Windows Explorer, locate the file named "VersaLASER.CPL", on the Software Installation CD-ROM, and copy this file over to the C:\Program Files\Corel\Corel Graphics 12\Languages\EN\Custom Data\Palettes folder.
6. While still in Explorer, locate a file named "corelapp.ini" located in the C:\Program Files\Corel\Graphics12\Config folder. Double-click on the file it will open up in Notepad. Scroll down past the semi-colons to the [Config] header. Then scroll down about 31 lines to the line that reads "FontRasterizer=1". Change the 1 to a 0 (this is a zero, not an o), save the file, and exit Notepad.
 
7. Open CorelDRAW 12 and start a new graphic.
8. In the menu bar, click on "Window", then "Color Palettes", and then click "None". Once again click "Window", then "Color Palettes", and then "Open Palette". In the pop-up box, double-click on "VersaLASER.CPL" which allows it to appear on the right side of the screen.


9. On the property bar, click on the landscape orientation (the sideways rectangle) (1). Enter the page width of 16 inches (406.4mm) (model VLS2.30) or 24 inches (609.6mm) (model VLS3.50) and height of 12 inches (304.8mm) (3). If you wish you can change the units from inches to millimeters (2).




10. The rulers on screen need to match the rulers in the VersaLASER. Adjust the ruler's vertical origin by double-clicking directly on the vertical (side) ruler. The "Options" dialog box will appear. In the vertical origin box, type in 12 inches (304.8mm). Click OK.




11. Set the default value for line width and color of the graphic objects, by clicking the outline tool and then the outline pen dialog in the flyout. With "Graphic" being the only selection checked, click "OK". Click the down arrow in the Color dropdown box to expand the list and click on the color **RED**. Click the down arrow in the "Width" dropdown box and click "Hairline". The units can be "inches", "millimeters" or anything else you prefer. Click "OK" to close the Outline Pen dialog box.



12. In the top menu, click "**Tools**", and then click "**Color Management**". Click on the down arrow to expand the "**Style**" dropdown list. Click "**Color Management Off**", and then click "**OK**".



13. Finally, at the top of the screen, click on "Tools", then "Options", then "Document", and then select "Save Options as Defaults for New Documents". Make sure **ALL** the options listed are **CHECKED** then click "OK".



14. The setup defaults for CorelDRAW 12 are now complete. Whenever you start a new document, all of the default settings that we had setup will automatically apply to the new document.


Remove the Software Installation CD-ROM from your CD-ROM drive and store it in a safe place.

CorelDRAW X3


Windows XP and Windows Vista

1. Make sure that you have installed all Service Releases and software patches from Microsoft. For Windows XP, install Service Pack 2. If you are reading this document from the Software Installation CD-ROM, as a service to you, you can find the file on this CD. For the latest releases, check Microsoft's website, www.microsoft.com. Please contact Microsoft if you have any questions regarding these upgrades. ULS is not responsible for any problems as a result from the usage of these patches.
2. If you have not already done so, install CorelDraw on your computer, but do not open it yet.
3. It is important that your version of CorelDraw is updated with the latest patches and service releases. For the latest patches and updates go to CorelDraw's website, www.corel.com. As of the date of this publication there are no updates available for CorelDraw X3. Be sure to check for any updates from time to time to keep your version up to speed. Please contact CorelDraw if you have any questions regarding these upgrades. ULS is not responsible for any problems as a result from the usage of these patches.
4. The ULS Windows Printer Driver must be loaded before continuing. Please refer to Section 2-5 on the manual on how to install the driver. If you have already installed the printer driver, you will need to re-insert the Software Installation CD-ROM back into your CD drive at this time.
5. Using Windows Explorer, locate the file named "VersaLASER.CPL" on the Software Installation CD-ROM, and copy these files over to the C:\Program Files\Corel\Corel Graphics SUITE X3 (13)\Languages\EN\Custom Data\Palettes folder.
6. Open CorelDraw and start a new graphic.
7. In the main menu at the top of the screen, click on "Window", then "Color Palettes", and then click on "None". Once again click on "Window", then "Color Palettes", and then click on "Open Palette". After the "Open Palette" pop-up box appears, double-click on "VersaLASER.CPL". The color palette will now appear on the right side of the screen.


8. On the property bar, click on the landscape orientation (the sideways rectangle) (1). If you would like the drawing units in metric, choose millimeters from the drop down list (2). Now type in the page width and height that matches your laser platform (3).




9. We now need to adjust the vertical ruler, on the left side of the screen, to match the rulers in the laser system. To do this, we need to adjust the ruler's vertical origin. Double-click directly on the vertical (side) ruler. The "Options" dialog box will appear. In the vertical origin box, type in the same height value as you did when you set up the page height in the previous step. For example, 12 inches for a VLS3.50. If you would like the scale to be displayed in tenths, choose "10 per Tick" in the "Tick Division" drop-down list box.




10. While still in the “Options” dialog box, double-click on “Global” to expand the list. Double-click on “Printing” to expand the list. Now click on “Driver Compatibility”. Make sure that the laser system's name is displayed in the printer drop-down list. In the settings specific for this driver dialog box, make sure that **ALL** the check boxes are **UNCHECKED**. Now click on “OK” to close the “Options” dialog box.



11. The next step is to set the default value for the line width and color when drawing graphic objects. To do this, click on the outline tool, then the outline pen dialog in the flyout. With “Graphic” being the only one selected, click “OK”. Click the down arrow in the Color dropdown box to expand the list and click on the color red. Click the down arrow in the “Width” dropdown box to expand the list and click “Hairline”. The units can be “Inches”, “millimeters” or anything else you prefer. Click “OK” to close the Outline Pen dialog box.



12. In the top menu, click “Tools”, and then click “Color Management”. Click on the down arrow to expand the “Settings” dropdown list. Click “Color Management Off”, and then click “OK”.



13. Finally, at the top of the screen, click on “Tools”, then “Save settings as Defaults”.
14. The setup defaults for CorelDRAW X3 are now complete. Whenever you start a new document, all of the default settings that we had setup will automatically apply to the new document.

Remove the Software Installation CD-ROM from your CD-ROM drive and store it in a safe place.

5. Unpacking and Assembling the VersaLASER



1. Remove the boxing material from the top of the shipping box by cutting the black plastic straps. Though not required but highly recommended; keep the box that the machine was packaged with in case the VLS machine needs to be sent back to ULS.



2. Remove any packing material and boxes that were placed on top of the VLS.



3. With the assistance of one or two other people, pick up the VersaLASER and place it on top of a table strong enough to support its weight (refer to the specifications section). To lift the unit properly, note the lifting points shown by the arrows above.




4. Completely open the access door by lifting up on the handle. Remove all packaging material that was placed with the top door. The motion system arm cover is hinged and is held down by magnets. Grasp the bottom of the cover and rotate it up to expose the motion system carriage. Remove the packing material that prevents the motion system carriage from sliding left and right. **YOU MUST DO THIS BEFORE PLUGGING IN THE POWER CORD OTHERWISE SERIOUS DAMAGE MAY OCCUR.**

5. Gently move the arm toward and away from you. It should slide freely.
6. Verify that ALL materials inside the VersaLASER have been removed.
7. Close the cover.


6. Finalizing the Connections

1. Power on your computer and boot into Windows XP. If your computer is already running, save your work and close all programs except Windows.
2. Connect the power cord from your power source to the power cord inlet (F) of the VersaLASER. **DO NOT** turn the VLS machine on at this time.
3. If you have an external exhaust system, connect your external exhaust hose to the exhaust port (E) and secure with a hose clamp.




Having a 9 volt battery installed into the VLS is necessary to operate the laser system. The laser system will not function without a battery or if the battery is low in power. Keep a spare 9 volt battery at hand at all times.

4. Install the Thermal Sensor battery (D) into the VLS system.




NOTE: If you purchased either the Computer Controlled Air Cleaner (CCAC) or the Computer Controlled Compressed Air Unit (CCAU), **DO NOT** connect their respective Serial cables to the VersaLASER at this time. We will address those options later in this section.

5. Connect the USB cable provided between the USB port of the computer and the USB port on the back of the VersaLASER. **Do not use a USB cable longer than 3 feet (1 meter).**



6. After connecting the USB cord, the Found New Hardware Wizard will open. You will be asked if Windows should connect to the Windows Update to search for software. Select "No, not at this time". Then click "Next" to continue.



7. Select "Install the software automatically". Then Click "Next" to continue. You **DO NOT** need to insert the Software Installation CD-ROM.



8. A message will appear, "The ULS VersaLaser Engraver Firmware Loader has not passed Windows Logo testing". Select "Continue Anyway". Do not be concerned. Installing the ULS Firmware **WILL NOT** harm your computer in any way! The firmware will begin to load.

9. The New Hardware Wizard will indicate when the installation is complete. Click "Finish" to close the Wizard.



10. You may notice a small pop up appear on the bottom right hand corner of your display screen saying "Found New Hardware VersaLaser USB Printing Support."
11. Another set of New Hardware Wizard windows will appear after the initial USB connection. Follow the same instructions as the ones mentioned above. Once completed your new hardware is installed and ready to use.

If you purchased the Computer Controlled Air Cleaner (CCAC) accessory and/or the Computer Controlled Compressed Air Unit (CCCAU), at this time, proceed to Section 6 of this manual and follow the installation instructions for that device. When you have completed the installation, return to this section to continue with the installation process.

Proceed to the next section to get step-by-step instructions to make a sample on the laser system.

Section 3




Running Your First Job

We will now illustrate how to use the VersaLASER with CorelDRAW X3 by creating a wooden keychain from the wooden sample that was packaged with your new VLS. In this example, we will etch and cut the key chain from a 2 by 4 inch, 1/8 inch thick piece of hardwood.

NOTE: In order to make a proper sample verify you have followed all Installation instructions up to this point.

Step 1 – Creating Your Artwork

Turn your computer on and open CorelDRAW X3 and create a new graphic. Draw some text using a **BLACK** colored fill and **NO** outline. For example, type in the word “KEYCHAIN”. Then, draw a **RED** hairline rectangular outline (with no fill) around the text and round the edges if desired. Add a circle (**RED** hairline outline also with no fill), for the key ring. Position the graphic, on your computer screen, in the upper left corner of the page as shown.



If you are not familiar with your graphics program run a few tutorials and become familiar with the graphics program. If tutorials were not provided you may have to learn the software on your own by experimenting with the software.

Step 2 – Printing Your Artwork

When you are ready to print the file, select PRINT, in CorelDraw X3, from the FILE menu. When the print dialog appears, ensure that the VersaLASER printer name is in the dropdown list, and then click the PROPERTIES button (Figure 3).





Figure 3

The VersaLASER printer driver will pop up (Figure 4). Choose your material by selecting the appropriate category from the material categories on the left (in this case wood) and then select the correct material type from the material types on the right (in this case hardwood). Since we are placing the material directly on the work surface, leave the Fixture Type set to NONE. If you were using an optional accessory or custom fixture you would choose it from the fixture list. Using a calipers or similar measuring device, enter the thickness of the material (in this case .125 inch). The Intensity control allows you to increase or decrease the already pre-programmed laser power setting. We suggest that you always leave it set to “0” until you are more comfortable using the system. When you have made all the appropriate selections and entered the material thickness, click OK. The printer driver closes and reverts back to the Print Dialog box (Figure 3) and now click on the PRINT button.

As the print job is being created, a small printer icon will appear in your taskbar in the lower right corner of your computer screen. Once the icon disappears the print job is completed and is now stored on your hard drive. Click on the VersaLASER icon in the taskbar  11:50 AM and the last print job will appear in the Viewer Tab of the Universal Control Panel (UCP) (Figure 5). Now click on the System Tab and verify that the Auto Z box is checked. Return to the Viewer Tab and proceed to the next step.




Figure 4




Figure 5


Step 3 – Powering On the VersaLASER

Once the UCP is running power on the VersaLASER by clicking the red POWER button on the UCP (Figure 5). The VersaLASER will always reset itself in the X-Y position when it is powered on. However, the Z-axis table will not reset unless you press the “home z” button. There is no need to re-home the Z-axis at this time. The VersaLASER’s laser tube fans will stop spinning after the system has powered on and it may appear like it is not operational. This is normal and the fans will start spinning once the VLS starts engraving.

Step 4 – Loading and Positioning Your Material

Open the top door and position the wood (1) into the upper left corner of the table, up against the rulers. If necessary, use the UP or

DOWN motion control buttons  on the UCP to raise or lower the Z-axis to make loading easier.



Step 5 – Running Your Job

If you have an external exhaust system, power it on now. If you have purchased the optional Computer Controlled Air Cleaner (CCAC), it will automatically power on when processing begins. Once your material is loaded and the access door is closed you can start your job by clicking the green START button on the UCP. The table will automatically rise to the appropriate focus height for proper engraving. Once processing is complete, wait a few seconds for the smoke to clear, or the CCAC to power off, then open the access door and remove the material. If you would like to repeat the process, load a fresh piece of material, close the door, and click START again.

NOTE: If you start the material process with the door open, the laser beam will not fire, but the Red Dot pointer will illuminate, showing you where the image will be located. If desired, you may use the center of the stroke as your center reference for positioning your material.

Step 6 – Powering Off the VersaLASER

When you have finished processing your materials and wish to power the VersaLASER off click the red POWER button on the UCP.




Congratulations! You have just completed your first engraving and cutting project with your new VLS.

The next section explains the Universal Control Panel (UCP), Printer Driver, and VLS keypad in further detail. If you have accessories or have questions about system maintenance sections 5 and 6 answer these questions.

Operation

How it Works

The VersaLASER uses the intense energy of the laser beam to vaporize material (wood, plastic, etc.), placed on the VersaLASER work surface, by using the technique of etching, cutting, or scribing the material. Etching is the technique where the laser beam traverses left and right, etching horizontal lines of material as it steps down the material vertically, similar to a laser or inkjet printer. Cutting or scribing is the technique in which the laser beam follows a path to cut or mark a desired outline, which is similar to a pen plotter. The difference between cutting (completely passing through the material) and scribing the material (lightly marking the surface), is laser power applied. You determine whether you want your artwork etched, scribed, or cut into the material by the colors you assign to the elements of the objects in your graphic images. Black colored (filled) and shades of black (grays or grayscale) objects will etch the material. Red colored outlined objects, set to a hairline thickness, will cut the material. Blue outlined objects, also set to a hairline thickness, will scribe the material.



Using the VersaLASER is as simple as creating your artwork, according to the rules outlined above, and simply printing to the VersaLASER as you would to any other type of printer. The VersaLASER printer driver will then pop up and prompt you for the type of material you are processing and its measured thickness. After choosing a material from the list and entering the material thickness, your artwork will be turned into a print job and stored in the VersaLASER print cache on your hard drive. You can then use the Universal Control Panel to select and preview the saved print job you wish to run, position your material in the VersaLASER, and click the START button.

The VersaLASER Keypad

- **POWER:** Turns the VersaLASER on ONLY if the computer is powered on, booted into Windows, the Universal Control Panel is running, and the USB cable is connected from the computer to the VersaLASER. Also, holding the key down for about 10 seconds will power off the VersaLASER.
- **UP and DOWN ARROWS:** Raises and lowers the Z-axis table (work surface). Press momentarily for slow movement and hold down for faster movement.
- **PAUSE:** If, during processing, you wish to stop or pause the VersaLASER, press PAUSE once. Press PAUSE again and the VersaLASER will resume processing from the point at which it was "paused". If you press START while the VersaLASER is "paused" the VersaLASER will start over from the beginning of the print job.
- **START:** Begins processing from the beginning of a job.
- **RED and GREEN LED's:** The RED LED and GREEN LED located between the PAUSE and START buttons provide information on the status of the machine.



CONDITION	RED LED	GREEN LED
OFF	The user door is closed	The VersaLASER is off
ON	The user door is open	The VersaLASER is on

The Universal Control Panel (UCP)

The purpose of the Universal Control Panel (UCP for short) is to be able to remotely control your VersaLASER by being able to view and print your stored print jobs. You will not be able to operate the VersaLASER without the UCP running in the taskbar.

Once you have installed the UCP using the installation disk, a blue square-shaped icon (Figure 1) will appear in the lower right corner of your Windows taskbar. This icon indicates that the UCP is active. It will automatically activate itself every time you power on your computer. If for any reason the UCP is deactivated you can reactivate it by double-clicking on the shortcut (Figure 2) found on your computers desktop screen. You can access the UCP at anytime by left-clicking once on the icon in the taskbar. The following describes the features of each tab of the UCP:



Figure 1





Figure 2


Viewer Tab


Selecting this tab will allow you to preview your file and control features of the laser system.

System Controls

- The green PLAY button starts engraving the currently displayed job on the Viewer.
- The red POWER button turns the VLS on or off.
- The PAUSE button halts the engraving process and moves the focus carriage to the upper right hand corner. To restart the engraving process click on the PAUSE button again. Clicking the PLAY button once it has been paused will restart the engraving process. **DO NOT** open the VLS's top door until it has homed to the upper right hand corner. Opening the top door before it finishes homing ruins the engraving process.
- These 4 motion control buttons  move the focus carriage back and forth or side to side.
- The final 2 motion control buttons  move the engraving table up or down.
- The button labeled "home xy" homes the focus carriage to the upper right hand corner. The button labeled "home z" homes the engraving table to the bottom of the VLS system.

Basic View (drop down list)


- Shows a preview window of the currently selected job.
- The cursor becomes a magnifying glass (Zoom Tool) if you pass it over the preview window. Left-clicking your mouse zooms in and right-clicking zooms out.
- Clicking the Settings button  takes you back to the printer driver. If mistakes were made or you would like to make additional changes clicking this button allows for those changes.



Further information about the printer driver can be found in Section 4-5 of this manual.

Focus View (drop down list)

- The "focus" button gives you the opportunity to move the focus carriage to a desired position on the laser systems table in order to manually focus the VLS machine (Section 4-6). To have a full range of motion of the X-Axis arm verify that you are zoomed out in the preview window by right-clicking on the mouse before entering the focus feature.




- The cursor will change into a blue cursor with dashed vertical and horizontal lines. Left clicking on the preview window will move the focus carriage to that location on the table.
- Clicking the GO button opens a small box allowing you to type in the exact X and Y coordinates where you would like the focus carriage to move. Once the coordinates have been typed click on the GO button to have the focus carriage moved to that location.




Estimate View (drop down list)

The “estimate” feature approximately calculates the amount of time it will take the VLS to finish the engraving or vector cutting job. The more complex the engraving job is the longer it will take to finish and visa versa.



Relocate View (drop down list)

If after sending the print job from your graphics program to the UCP you decide you want to engrave it in another location within the engraving field this feature gives you the opportunity to move the graphic within the basic view screen.



When this feature is activated the image is surrounded with 9 small white squares (anchor points) and allows you to move it around the basic view screen. The current anchor point selected, in blue, is the axis of movement.



We recommend you write down the original coordinates in case you would like to reposition the graphic in its original location.

Relocation Types

1. You can click on any anchor point available to move the graphic within the basic view area.
2. If you would like to move the graphic to the upper left hand corner select the top left hand anchor point and type in your desired X Y coordinates into the boxes that appear on the right hand side. This process can be done with any available anchor point.
3. Enter the XY menu on your ILS keypad. Using your motion control keys move the focus carriage to your desired location where you would like the image to be placed. Use the red LED as a reference point. Go back to the UCP and click on the TO CARRIAGE button. According to the anchor point you selected the image will move in reference to the location of the focus carriage's red LED.


File Management

Displays the name of current job, the number of files stored, the date and time it was stored on your hard drive, and the run time near the top of the window.

- The print job navigation buttons  allow you to preview the print jobs stored on your hard drive.
- The “open folder” button  displays and allows you to select your print jobs in a file management style. It also allows you to delete print jobs stored from your hard drive, and save print jobs as .efm files.

System Tab

- The PRINT CACHE number is adjustable. It indicates the maximum number print jobs that you would like to be stored on your hard drive. If you exceed the number shown, the software will automatically begin deleting the oldest jobs as newest ones enter the cache.
- LANGUAGE allows you to switch between multiple languages according to your preference.
- If the laser machine was improperly shut down the engraving table will home at start up. To have this feature turned off, check the Disable box under AUTOMATIC Z-HOMING. Disabling this feature can also be helpful when troubleshooting Z-Axis problems.
- UNITS allows you to choose between English or Metric units.
- AUTO Z should be enabled if you would like the device to focus the laser beam by automatically adjusting the height of the Z-axis table. This operating principle is based on the material thickness that you specify in the VersaLASER Printer Driver (Section 4-5). If it is disabled, you will need to set focus manually by using the included Focus Tool (Section 4-5).
- The TUNING number is a value set by the VersaLASER manufacturing factory for your particular machine. In the future, as your system gets broken in, it may be necessary to change this value to sharpen the resulting image. Do not change this number unless instructed to do so by our Technical Support Department.
- The LENS SIZE selected from the list should be the same as the number printed on the lens assembly on the front of your VersaLASER's Focus Carriage. If you change lenses (available accessory) other than the standard 2.0, then you **MUST** select the value that matches your installed lens and calibrate the focus lens to the top surface of a table by clicking the red CALIBRATE button, otherwise your VersaLASER's laser beam will not be focused properly. You need to have the engraving table installed in the VLS to have access to the CALIBRATE button. Contact the Technical Support Department if you have any question about lens calibration.
- The ALIGNMENT Launch button opens the Alignment Mode window.
- CUTTING TABLE allows you to calibrate a new Z-height to the top surface of VCA table. You need to have the VCA table installed in the VLS to have access to the CALIBRATE button.
- The ROTARY Calibrate button permits you to adjust the focal length to the top of the metal cone of the rotary for proper engraving. The rotary needs to be installed to have access to the ROTARY Calibrate button.
- If any of the SOUNDS boxes are checked the appropriate sound will play on your computer once the feature checked is completed by the laser system. Be sure that your computer speakers are turn on and at an appropriate volume.



Diagnostics Tab

The Diagnostics Tab displays important information about your laser system and personal computer.

- ENGRAVER shows the current firmware and FPGA version being used. It also displays the System Serial number of your laser system.
- COMPRESSOR displays the current device being used, shown by a green check mark, to supply compressed air to the laser system. If a ULS Compressor is connected it will show the firmware version.
- LASER displays the laser tube(s) current wattage. If a red 'x' appears this indicates that the laser tube is not functioning properly or a door is opened on the laser system.
- OTHER DEVICES displays the current firmware version of the Keypad/Display on the laser system. It also displays the current firmware version of the Homing Sensor on the laser system.
- The FILTER box displays the current filters on the laser system and the remaining filter life.
- SYSTEM displays information about your personal computer.
- ALARMS alert you if the inside of the laser system is above the recommended temperature or if the Thermal Sensor battery is low in power. If the Thermal Sensor inside the laser system is triggered an alarm will sound and shut down your laser system.
- INTERLOCKS show you if the Top Door is Opened or Closed.
- FIXTURES indicate if an engraving table, cutting table, or rotary is installed.



Printer Driver Controls

This section describes the use of each of the features of the printer driver.

Materials Database Tab


This window is seen once you change the properties of the printer driver. This tab controls the printer driver settings for engraving or cutting the material being processed in a simple manner.

Category List

This section allows you to choose from 8 original types of material categories.

Material List

Once you choose a category a variety of material types will appear to the right of the category section.



Intensity Adjustments

Intensity Adjustments give you the opportunity to change the intensity of your Raster Engraving, Vector Marking, and Vector Cutting. The default settings are set to 0% but they can be changed from -50% to +50%. Increasing the settings increases the intensity of the engraving process giving you deeper results. Decreasing the intensity decreases the engraving process and gives you shallower results. Always start at 0% on a scrap piece of material and make any appropriate changes accordingly. There is not need to make changes to these controls only if undesired results are produced.

Material Thickness

In order for the laser system to properly vector cut and/or engrave on the material it needs to know the thickness of the material before it starts engraving. Using a caliper or similar measuring device, measure the thickness of your material and enter it into the Material Thickness box.

Units

This section allows you to switch between Metric and Inches.

Fixture Type

NONE

If you are not using any type of fixture set the drop down menu to NONE.

ROTARY

If you have purchased this accessory read how to install and operate this fixture in the ASSECCORIES section of this manual.

CUSTOM

If you prop up the material you are going to engrave on a surface other then the table provided, you will need to add the height of the prop in the Height field.

Save Button

By clicking Save, the "Save Engraving Setup" dialog box will appear and will allow you to enter in a file name. All settings will be stored in this file that has a ".LAS" extension. DO NOT rename the extension; the driver will not recognize the file as a laser settings file if it does not have the ".LAS" extension name. These files can be stored in any directory on your hard drive and you can have as many setting files as your disk can hold.



Load Button

To recall printer driver settings that have been previously saved, click on the "Load" button and choose the desired .LAS settings file. The settings that are currently on screen will be replaced by the settings from the .LAS file. You may abort this change by clicking Cancel; clicking OK will approve the change.

Manual Focus

Manually focusing the laser beam while using the Materials Database is not necessary, however using certain types of accessories requires you to manually focus on the top of the material surface or table.

1. Turn on your UCP and VersaLASER.
2. Verify that the appropriate LENS SIZE on the System Tab matches the number printed on the plate of the Focus Carriage.
3. Position the Focus Carriage (1) above your material or table.
4. Place the Focus Tool on top of the material (2) or table.
5. Raise or lower the Z-axis table using the UP and DOWN keys on the VLS keypad so that the flat edge of the tool rests against the front side of the Focus Carriage (3). Slowly raise the table until you observe the tool either tilting or sliding away from the Focus Carriage (4). This will occur when the bottom edge of the Focus Carriage meets with the top of the beveled edge of the Focus Tool (5). The objective is to stop moving the table at the point where the tool just starts to move or tilt.



Practice this technique several times to properly focus the laser beam on top of the surface.




WARNING: To avoid damage to the focus lens, avoid positioning the focus tool underneath the focus carriage.

Sometimes it is desirable to be slightly out of focus when engraving or cutting. It widens the beam at the surface of the material to soften the image or create a wider cut line.



WARNING: DO NOT engrave or cut too far out of focus, as this can be a potential fire hazard. A maximum of .05 inches above or below precise focus should be the absolute limit.



Basic System Maintenance

Keeping the VersaLASER clean will ensure the highest quality performance and prolong the lifetime of the mechanical components. The frequency of cleaning will depend entirely on the type of material being processed, the performance of your exhaust system, the operating environment, and the amount of laser system usage. Dirt or debris that is allowed to build up on the motion system components may cause a poor quality image, loss of mechanical position, and may cause premature mechanical component failure. Optical contamination will result in loss of laser power, or premature failure of the optic. Use good judgment and keep in mind that a clean machine is the best performing machine.



WARNING: Failure to properly and adequately maintain your VersaLASER may invalidate your warranty.

Safety

- Always make sure that the VersaLASER is powered off and is unplugged before performing any cleaning or maintenance procedure.
- When using any chemical, be sure to follow the safe handling procedure printed on its label.
- **NEVER** pour or spray any chemical directly onto or into the VersaLASER. Always dampen your cotton swab, paper towel, or cloth, with the cleaning solution, outside of the machine and then wipe down the appropriate part.
- Use only the appropriate chemical to clean specific parts of the system otherwise cosmetic or operational damage may occur. Pay strict attention to the cleaning procedures outlined in this section. Unapproved chemicals and inappropriate cleaning methods may invalidate your warranty.

Cleaning and Maintenance Supplies


- Vacuum cleaner
- Soap solution mixture of 1 tablespoon (2 cl) liquid soap and 1 quart (liter) of water in a spray bottle
- Paper towels, cotton cloth or terrycloth, normal facial tissue
- Denatured alcohol
- Regular acetone and reagent grade acetone
- Cotton swabs
- Lens cleaner (supplied)
- Set of Allen wrenches sized from .050 to 3/16 inch

Optics

A visual inspection of the optics should be performed at least once a day. If the optic appears cloudy or has material deposits formed on the surface, it should be cleaned. If, after inspection, the optic appears visually uncontaminated, **DO NOT** clean the optic. Excessive cleaning can damage the optic. The guidelines listed below describe how to handle optics:

Optics Handling Guidelines


- Wash your hands thoroughly before handling any optic.
- **NEVER** touch the surface of the optic with your fingers.
- **NEVER** clean any optic immediately after using the VersaLASER. Wait for the optic to cool, at least 3-5 minutes, otherwise it may crack from thermal shock.
- **DO NOT** use compressed air to clean the optic.
- **DO NOT** clean an optic that is visually clean. Excessive cleaning may damage the optical coating.
- Use only cotton swabs and approved lens cleaner or reagent grade acetone to clean the optics.



Optics Cleaning Procedure

- Dampen an unused cotton swab with lens cleaner.
- **GENTLY** wipe the optical surface with the damp swab. **DO NOT RUB HARD.**
- Control the wiping speed so that you do not leave streaks. If streaks remain, dampen an unused cotton swab with reagent grade acetone and gently wipe the optical surface to remove the streaks.



Accessing the Optics





1. Slowly slide the X-axis Arm (1) forward.
2. Grasp the bottom lip (2) of the cover.



3. Rotate the cover (1) up and over the top of the X-axis Arm. The cover is held down by magnets so it may "stick" slightly when you first begin to pull it forward.

#2 Mirror

1. Locate the #2 Mirror Holder (red). Grasp its protruding handle with your thumb and forefinger and slide it out. It is held in place by magnets so you may feel a slight resistance when you begin to slide it out. The picture reveals the backside of the mirror.
2. Turn the #2 Mirror Holder over and inspect the optic for visual contamination. Clean as necessary.
3. Re-insert the #2 Mirror Holder by sliding it into the mounting slot until it stops. **NOTE: Installing the mirror backwards will cause the handle to protrude in such a way that the X-axis Arm cover will not close properly and will destroy the mirror once the laser beam penetrates the backside of the mirror so be sure that you re-install the mirror correctly.**

#3 Mirror and Focus Lens

1. Loosen the two thumbscrews (2) completely. They are held captive by retaining clips so they will not come out all the way.
2. Grasp the red Front Cover Plate (3). Gently slide it forward and out of the Focus Carriage (1).
3. Inspect the #3 Mirror (1) and Focus Lens (2) and clean as necessary. Be sure to inspect the top and bottom side of the Focus Lens.


Beam Window

- The Beam Window (1) is where the laser beam enters into the processing area. It is located in the upper left hand corner, towards the rear of the machine.
- It is only necessary to clean the front side of the Beam Window. The backside is in a sealed environment and should not get contaminated.
- **DO NOT** remove the Beam Window for inspection or cleaning. Inspect the optic in place and clean if necessary.




The Motion System

- Using a vacuum cleaner, vacuum all loose dirt and debris from the inside of the device.
- Outside the device, dampen a paper towel, cotton cloth, or terry cloth with the soap solution, alcohol, or acetone and wipe down the Z-axis Table. Be careful not to spill any chemical on any painted surface.



- Locate the four X-axis Bearings (1). Dampen a cotton swab with a soap solution. Place the dampened swab against the bearing (2), grasp the focus carriage (3), slide the focus carriage left and right, allowing the bearing to roll in the v-groove (4). Pay attention to the part of the bearing that contacts the v-groove both on the top and the bottom side of the bearing. Also, use the dampened swab to clean the v-groove (4). Make sure you clean all 4 bearings.



- Locate the left and right side Y-axis Rails and their respective v-grooves as the arrows in the photos indicate. This is where the Y-axis Bearings (not visible) make contact with the rail. Dampen a cotton swab or cotton cloth with a soap solution, and clean the v-groove. Gently slide the X-axis Arm towards the front or rear of the device so that you have access to the entire length of the v-groove.

The Main Enclosure

- Clean the glass user door with a non-abrasive cotton cloth, paper towel or facial tissue and window cleaner. The top window is made out of glass; therefore, **DO NOT** use abrasive cleaning clothes because they will scratch the glass. Also, **DO NOT** use abrasive chemicals that will damage the glass. Only use cleaners compatible with glass.
- Use a soft cloth dampened with the soap solution to clean the enclosure. **DO NOT** use alcohol, acetone, or any other harsh chemical, as this will damage the paint.

Adjustments and Lubrication

- Periodic adjustments are not required.
- The bearings in the motion system will self adjust to take up any clearances as they begin to wear. All bearings in the system are sealed and do not require lubrication. **DO NOT** lubricate the bearings.
- The belts are fiber reinforced and will not stretch under normal use.
- Optical alignment is not necessary under normal use.


Interlock Safety Check

As mentioned earlier in the Safety section of this manual, the user door is safety interlocked. To verify that it is functioning normally, perform the following test:

Power on the VersaLASER. Without any job running, open and close the user door. Observe the Red Dot Pointer turning on and off respectively. If there is no change while opening and closing the door, power off the VersaLASER and contact our Technical Support Department immediately. **DO NOT** use the device until the problem has been corrected.


Fuse Replacement

If the power input fuses are blown, this indicates that there is a problem with a component inside the VersaLASER and that component must be repaired or replaced otherwise the replacement fuses will blow also. Please contact our Technical Support Department if the fuses blow.



The fuses are located on the bottom of the power input plug receptacle. To remove and check or replace the fuses, use a small screwdriver or your fingernails to push the two retaining tabs (arrows) toward each other and pull out the fuse holder. Pull out the two fuses from the holder and check them with an ohmmeter or for visual damage. When reinstalling the fuses, be sure to push the holder in all the way until it “clicks” into position.

Cooling Fan Filters



The side (1) and rear (2) cooling fan filters are located inside the Rear Cover. To access them, remove the two mounting screws (3) underneath the rear of the system. Lift the cover straight up and off. Locate the filters on the inside of the cover (not shown). Remove the plastic retainer and the filter media. Rinse the filter media with soap and water. Allow them to air dry off or dry them off before re-installing.

Maintenance Schedule

Since the maintenance requirements of the VersaLASER is dependent on the type of material being run, the quantity of material being removed, the hours of operation, and the quality of the exhaust blower, it must be user defined.

However, as a starting point, we recommend the following schedule:

- As necessary
 - Work Table
 - Main enclosure
 - User door
- Every 8 hours of processing
 - Clean X-axis bearings and bearing tracks
 - Check Beam window, #2 Mirror, #3 Mirror, and Focus Lens for debris. Clean **ONLY** if dirty.
- Every month
 - Clean side and rear cooling fan filters
- Every 6 months
 - Exhaust plenum

If you are noticing a considerable buildup of debris on the optics and the motion system, clean the system at more frequent intervals. If your system has remained relatively clean, you can extend your cleaning intervals. Keep in mind that a clean machine is a better performing machine and can extend the life of the parts as well as reduce the possibility of down time. If you have any questions about maintaining the laser system, please contact our Technical Support Department.


Accessories

As an addition to the regular VersaLASER, we offer a wide variety of optional accessories. **Before attempting to use any of the accessories in this section, make sure that you are comfortable operating the VersaLASER, the UCP, and your graphics software.**

Cylindrical Object Rotary Accessory (CORA)

This accessory allows the VersaLASER to be quickly reconfigured to etch, scribe, or cut (material dependent), cylindrical objects such as glassware, etc.


The smallest object that can be placed in the rotary accessory for engraving is a 1" (2.54 cm) diameter object.




NOTE: If this is your first time using the CORA, we highly recommend that you practice this procedure several times on some inexpensive scrap material before attempting to etch the actual object.

Calibration and Installation

1. Turn on the UCP and VLS.
2. Open the top door.
3. Lower the table all the way **DOWN** to the bottom of its travel so that you can remove the table.





4. Remove the table by loosening the two captive thumbscrews (1). Insert your fingers into the two holes (2) and slowly lift the table out of the VersaLASER being careful not to bump it around.



5. Inside the VersaLASER you will find the large recessed slot with a self-aligning electrical connector to the right side (1) and the two alignment pins (2).

6. Now raise the Z-axis platform as high as it will go by using the VLS keypad or UCP.




7. Proceed to the UCP and activate the focus feature on the right hand side of the Viewer Tab. Click within the focus feature and have the focus carriage move over the alignment pin as shown. Use the red LED to position the focus carriage over the pin properly. You can also use your computers keyboard to control the movement of the focus carriage when you are using the focus feature. **DO NOT** exit the focus feature yet.




8. Next, proceed to the System Tab and click on the Rotary CALIBRATE button. The Rotary Calibration window appears. Click on the Y Position SAVE button. If it asks you to override the current position accept the new number. Once the Rotary Calibration window is closed the focus carriage will re-home.


9. Go back to the Viewer Tab and exit the focus feature.
10. Lower the table all the way **DOWN** to the bottom of its travel.




11. On the underside of the CORA notice the self-aligning electrical connector (1) and two alignment holes (2).



12. Insert the CORA into the slot (OK to do with the power on because it is hot swappable) and move it around until the connector engages, the pins protrude through the alignment holes, and the fixture sits flat. It will indicate that it is installed properly by automatically rotating its cone slightly.



13. Using the same procedure in step 7 use the focus feature and move the focus carriage's red LED over the flat part of the metal concave fixture. Now use the focus tool and manually focus on top of the flat part of the metal concave fixture as described in Section 4-5. **DO NOT** focus on top of the black metal cover normally located on the left hand side of the rotary.



14. Once you have manually focused proceed to the System Tab and click on the Rotary CALIBRATE button. The Rotary Calibration window appears. Click the SAVE button for the Z Position **ONLY**. If it asks you to override the current position accept the new number.

15. CORA calibration is now done. CORA calibration does not need to be done again unless the VLS's CPU is changed or calibration settings are changed. Verify that the system re-homes before you proceed to the next steps.

Basic Operation


In this example, we are going to etch a simple drinking glass.



1. Before loading the glass into the fixture, using a dry erase marker or some other marking device, make a mark on the glass where you would like the place the **TOP CENTER** point of the graphic.




2. Using a caliper or similar measuring device, measure the diameter across the area of the glass where you marked. Either remember this number or write it down.



3. Lift the lever (1) on the adjustable end of the fixture (2) and slide it to the left, out of the way. Place the open end of the glass into the cone, and slide the adjustable end of the fixture to the right (3) up against the base of the glass so the glass rests firmly centered inside of the inverted cone. Apply light pressure to the right, only enough force to prevent the glass from slipping while it rotates, and push the lever down (1) to lock it in place. By hand, rotate the cone or the glass, until your mark points as straight up as possible. The electrical power to the CORA motor is lowered when it is sitting idle so that you can rotate the cone of the fixture easily. This is OK and will not damage the CORA.

4. Start the UCP if it's not already running. While on the Viewer Tab click on the "focus" button located on the right hand side of the UCP. While on the "focus" window click within the white area where the glass is located.




5. Now you will need to align the Red Dot pointer with the center of your mark by using your mouse to click on the main window in the Focus feature of the UCP. The Red Dot will move to the location where you clicked (or type in the coordinates in the X-Axis and Y-Axis boxes by clicking on the GO button.) Adjust the position of the Red Dot until it lines up with your mark, left and right. If your mark does not line up with the Red Dot in the rotational direction, simply grasp the glass or the cone and manually rotate it while it is in the fixture.

6. Continue repositioning until the Red Dot is on top of your mark. Locate the X-axis coordinate number on the right hand side of the UCP. Either write this number down or remember it. This is the coordinate of the Red Dot pointer and it is also where you will need to position your graphic. Ignore all other coordinates. When it is aligned exit the "focus" feature by clicking the "focus" button in the UCP. The focus carriage will go back home.
7. Once the focus carriage re-homes verify that Auto Z is enabled on the UCP's System Tab before engraving.

Graphics Setup

Open your graphics software. In this case we will use CorelDRAW X3 and create a new graphic.

Using the Transformations menu, rotate your graphic 90 degrees to the right to match the glasses orientation. Reposition your graphic so that its **RIGHT CENTER** anchor point, which was the **TOP CENTER** before we rotated it 90 degrees, is located at the same X-axis coordinate as the Red Dot pointer. The vertical placement of where you position your graphic within your graphic software is irrelevant because the UCP will automatically match the vertical center of the graphic with the mark you placed on the glass. Just make sure that the graphic is positioned within the printable area.




Printing



The following steps are critical. Make sure that you enter the correct information otherwise the VersaLASER might not only adjust the Z-axis and scale the graphic incorrectly, which can ruin your material, but it can also damage itself if the moving parts of the X-axis crash into the CORA.

Print as if you were etching a flat object. When the VersaLASER Settings dialog box pops up, choose your category and type of material as usual. In the Fixture Type section, select **ROTARY** from the dropdown list and also type in the diameter of the glass that you measured earlier and click OK then Print. As usual, the print job will be stored on your hard disk and become available in the UCP as the next job ready to be processed. To start the engraving process, click on the **START** button.



For each glass that you would like to etch your graphic in a precise location, you must follow each of the steps from the beginning of this section with the exception of the Calibration. If it does not matter to you if the etching begins anywhere around the circumference of the glass, then simply load the next glass and run the job again without having to make any marks or lining up the Red Dot.

Once you have practiced using the CORA, you will naturally come up with shortcuts to save on setup time.



Vector Cutting Accessory (VCA)

The Vector Cutting Accessory, with its honeycomb design, assists with the vector cutting of materials by minimizing the surface contact area of the backside of the material. This simple yet functional design also provides a slight vacuum for sheet stock to hold it flat while cutting, and it assists with smoke removal by drawing it down and underneath the material.





Installation

1. Turn on your VLS machine by clicking on the red POWER button on your Universal Control Panel.
2. Lower the table all the way down to the bottom of its travel or down far enough so that you can remove the table and install the VCA without interfering with the moving parts of the VersaLASER.



3. Remove the table by loosening the two captive thumbscrews (1). Insert your fingers into the two holes (2) and slowly lift the table out of the VersaLASER being careful not to bump it around. On the underside of the VCA find the self-aligning electrical connector (3) and two alignment holes (4).




4. Inside the VersaLASER you will find the large recessed slot with a self-aligning electrical connector to the right side (1) and the two alignment pins (2).
5. By using the thumbscrews as handles (3), insert the VCA into the slot (it is OK to do with the power on because it is hot swappable) and move it around until the connector engages and the fixture sits flat. DO NOT raise the table at this point.

Focus Lens Calibration



To properly use the VCA for the first time you **NEED** to calibrate your focus lens to the top of the VCA surface. If you do not calibrate the focus lens the focus carriage may cause damage to your VCA and focus carriage.

6. After you have installed the VCA into your VersaLASER, manually focus to the VCA surface by following the instructions in Section 4-5.
7. Once that is complete, go directly to your System Tab and you will notice that the red CALIBRATE button for the Cutting Table box will be activated. Click on the CALIBRATE button. A window will appear. To accept the new Z-height click on SAVE. You are now done calibrating the new Z-height for engraving or cutting on the VCA.




Graphics Setup

Next, open your graphics software. In this case we will use CorelDRAW X3 and create a new graphic. Layout the graphic the same way as if the regular table is installed.

The border of the honeycomb material of the VCA is slightly larger than the printable area of the VersaLASER. Since there are no reference rulers attached to the table, if you desire, you can use the Red Dot pointer as your positioning reference.

Printing

Print as normal. When the VersaLASER Settings dialog box pops up, choose your category and type of material as usual. In the Fixture section, select **NONE** from the dropdown list. Using a caliper or similar measuring device, measure the thickness of your material and enter it into the Material Thickness box and click OK then Print. As usual, the print job will be stored on your hard disk and become available in the UCP as the next job ready to be processed. The VersaLASER automatically knows that the VCA is installed and it will automatically compensate for the focus height difference according to the Focus Lens Calibration done in the previous steps. Proceed to the System Tab on the UCP and verify that Auto Z is enabled. Place your material directly on the VCA and proceed to cut.



Note: You may experience a slight “notching effect” on the backside edge of the material. This is due to the reflectivity of the honeycomb material and is normal. To reduce the effect, try reducing the Intensity settings. To completely eliminate the effect, you may want to elevate your material off of the honeycomb by using some sort of spacers, at least 1/8th to 1/4 inch thick, between the honeycomb surface and your material that does not interfere with the beam path. If you are to do this, be sure to select Custom for the Fixture Type and enter the thickness of your spacer in the Height box.

Integrated Cart

Features:

- Size: 25"W x 22" D x 30"H / Weight: 95 lbs
- Maximum stability at low cost / Powder-coated, durable construction
- Four "foot" ports to secure the VersaLASER to the cart to prevent slipping (1)
- Two large storage drawers (2 & 3)
- Locking casters for moving convenience (4)



Installation



1. Push down on the tabs of the locking casters so that the cart does not roll.
2. Obtain the assistance of another person. One person should grasp the front of the machine and place his hands where the arrows indicate. The other person should stand in the back of the machine and place his hands where the arrows indicate.
3. Pick up the VersaLASER, place it on top of the cart and locate the VersaLASER's four feet into the four, foot ports.
4. If this is the first time you will be making connections to the VersaLASER, proceed back to Section 2 to complete the installation process.

Computer Controlled Air Cleaner / Cart (CCAC)

Features:

- Size: 25"W x 22" D x 30"H / Weight: 200 lbs
- Eliminates smoke, dust and fumes from processing.
- Controlled through a Serial port connected to the VersaLASER and is activated only when jobs are in process
- Filters are concealed within the two drawers
- Foot ports to secure the VersaLASER to the cart to prevent slipping
- Powder-coated, durable construction
- Locking casters for moving convenience



Figure 1 (Front View)

1. Four "foot" ports to secure the VersaLASER to the cart and prevent slipping (1)
2. Pre-filter and HEPA filter drawer
3. Charcoal filter drawer
4. Locking casters




Figure 2 (Rear View)

1. Exhaust intake port
2. Cable retainer clips
3. Serial port
4. Exhaust output port
5. Power inlet, electrical power requirement label, Warning label, fuse holder

How it works

This device contains a pre-filter to remove coarse (larger) particulates, a HEPA filter to remove fine (smaller) particulates, an activated charcoal filter to remove fumes and odors, and a high-pressure vacuum motor to pull these byproducts through the filters. It also serves as a moveable base, or stand, for the VersaLASER. To reduce noise, minimize electrical consumption, and prolong filter life, the CCAC is controlled from the VersaLASER via a Serial cable. The VersaLASER powers on the CCAC when processing begins and powers it off a few seconds after the processing completes to remove any remaining particulates, fumes, or smoke.

NOTE: When the filters are reaching their useful life, the UCP software will prompt you and inform you how much of a percent of its useful life has expired, starting at 85%. That would be a good time to reorder filters. This message will only appear if you are using the Materials Database to engrave your projects. Keep in mind that the CCAC will only work while using the Materials Database.

The air cleaner is recommended only if you have no other choice than to filter the exhaust. Keep in mind that it is designed as a light-duty device and heavy usage will result in the high consumption rate of the filters.

Installation



1. Push down on the tabs of the locking casters so that the cart does not roll.
2. Obtain the assistance of another person. One person should grasp the front of the machine and place his hands where the arrows indicate. The other person should stand in the back of the machine and place his hands where the arrows indicate.
3. Pick up the VersaLASER, place it on top of the cart and locate the VersaLASER's four feet into the four, foot ports.

Making the Connections



NOTE: Before continuing, you **MUST** have completed Section 2 of this manual which includes loading the VersaLASER Installation Software. If not, go back to that section, complete the installation, and return here.

1. Connect the short exhaust hose and secure it with the provided hose clamps (1) and install the sheet metal cover over the exhaust hose.
2. Make sure your computer is powered on and booted into Windows.
3. As instructed in Section 2 plug in a power cord to the VersaLASER's power inlet (6) then attach a USB cable from your computer to the VersaLASER USB port.
4. Plug in a power cord to the CCAC's power inlet (5) and then connect a 3 ft. Serial cable between the first or second Serial port (2) of the VersaLASER and the Serial port located towards the bottom of the CCAC (3).
5. Secure the Serial cable using the retainer clips (4).

Computer Controlled Compressed Air Unit

This integrated accessory provides dry, oil-free compressed air to protect the VersaLASER's optics and assist with cutting and etching of materials that tend to flame up or produce heavy quantities of smoke or debris. It **MUST** be used in conjunction with either the Air Assist Cone or AABS accessories. The Air Compressor is designed to automatically power on when the VersaLASER starts a print job, and then power off automatically and finishes it.





WARNING: The use of compressed air IS NOT intended to decrease maintenance of the VersaLASER. Actually, it has been known to increase the frequency of cleaning maintenance due to debris being blown around, inside the machine, during processing.

This device is not intended for continuous use (longer than 20 minute jobs), nor high-humidity environments, otherwise serious damage to the compressor may occur. If you need an air unit capable of heavy duty use and/or high humidity environments, please contact our Sales Department.


Features:

- Size: 12"W x 6" D x 14"H / Weight: 14 lbs
- Controlled through a Serial port connected to the VersaLASER and is activated only when jobs are in process
- An air dryer is integrated into the unit to remove the moisture that can damage the optics.
- Noise insulated for quiet operation.
- Powder-coated finish, durable construction.

Installation



1. Push down on the release lever (1) of the fitting on the back of the VersaLASER until it "clicks". Insert one end of the blue hose into the fitting until it also "clicks".




2. Connect the other end of the blue hose to the Air Compressor (1) in the same fashion. Plug in a power cord from your power source to the power inlet (3) of the CCCAU.

NOTE: Before continuing, you **MUST** have completed Section 2 of this manual which includes connecting the USB cable and power cord to the VersaLASER and loading the VersaLASER Installation Software. If not, go back to that section, complete the installation, and return here.

3. Make sure your computer is powered on and booted into Windows.
4. Connect a 3 ft. Serial cable between the VersaLASER's Serial port and the Serial port (2) located towards the bottom of the CCCAU.

Periodic Maintenance

At least once per month, check the condition of the two filters on the back of the device. If they are plugged, simply remove them by snapping off the cover, removing the filter media, washing it out with ordinary soap and water, dry the filters, and re-install. If the filters remained relatively clean, adjust your maintenance schedule accordingly.



Below the device you will find a tray. With your hands, slide the tray forwards. Inside the tray you will find sponges that are designed to absorb the water that was generated from condensation. In humid areas you may need to check the sponges more than once per week. In drier areas it is possible to extend that period. Check them at least once per week and adjust your schedule accordingly. The sponges may need to be cleaned with soap and water and dried out, or replaced.

Air Assist Cone (AAC)


This accessory also requires the CCCAU.




NEVER install the AAC without having the CCCAU installed and operating, and **NEVER** shut off the needle valve completely. The lack of pressurized air present in the cone, during processing, will allow smoke to contaminate the lens and can destroy it within seconds.




The cone attaches to the base of the Focus Carriage and will force air directly onto the surface of your material to reduce the burning effects of the material from the laser beams intense heat. It also helps disperse the smoke and gases that are created from the processing of materials. It contains a needle-valve assembly to control airflow through the cone.

Installation

1. Lower the table down far enough so that you can attach the cone. Power off the VersaLASER. By hand, move the X-axis arm and Focus Carriage to a comfortable working position in the field. Remove (if present) the plug (1) with a screwdriver.



2. Using a 3/16 socket tool or 5mm wrench, attach the needle valve to the port where you removed the plug. Be careful not to cross-thread the small device when installing and do not over tighten it.



3. Loosen the thumbscrew (1) on the side of the Focus Carriage (if already attached). Insert the cone (2) by pushing it straight up into the bottom of the Focus Carriage ensuring that it is up all the way and is seated properly, and gently tighten the thumbscrew. If this is the first time using the cone, open the needle valve (3) all the way, counter clockwise. This will result in maximum airflow through the cone. To lock the adjustment in place, rotate the round locking nut (4) clockwise until it seats.

Usage

Power on the VersaLASER and run a job. Make sure that the CCCAU unit turns on (if purchased) or your compressed air source is operating when the job starts processing. Observe how the smoke is pushed away from the tip of the cone. If you would like to reduce the flow, pause the job and adjust the needle valve as necessary.



NEVER install the AAC without having the CCCAU installed and operating, and **NEVER** shut off the needle valve completely. The lack of pressurized air present in the cone, during processing, will allow smoke to contaminate the lens and can destroy it within seconds.

Removal

Loosen the thumbscrew and pull the Cone downwards. Leave the thumbscrew attached to the Focus Carriage by re-tightening it so that it doesn't get lost. Either detach the accessory by unscrewing the needle valve and reinstalling the plug (the same way you installed it), or by the preferred method of un-attaching the hose from the needle valve by either using a wrench to loosen the nut at the end of the hose or by simply using the cone as your wrench and turning it counter clockwise. This way, the needle valve remains attached to the Focus Carriage for the next time you install the Cone. The same needle valve is also used for the AABS accessory.



Air Assist Back Sweep (AABS)

This accessory also requires the CCCAU.


The AABS attaches to the Focus Carriage and is used to force compressed air either directly onto the surface of your material, from an angle, or it can be adjusted to where it can blow the smoke straight back to the Exhaust Plenum or at various, user defined angles. This accessory can be used to reduce the burning effects of the material from the laser beams intense heat, or to direct the smoke away from the beam during processing. It contains a needle-valve assembly to control airflow, one height adjustment, and one angle adjustment.



Installation



1. Lower the table down far enough so that you can easily attach the AABS. Power off the VersaLASER. By hand, move the X-axis arm and Focus Carriage to a comfortable working position in the field. Remove (if present) the plug (1) with a screwdriver. Attach the mounting block (2), if not already attached, with the 4-40 screw and using a 3/32 Allen wrench.
2. Using a 3/16 socket tool or 5mm wrench, attach the needle valve (1) to the port where you removed the plug. Be careful not to cross-thread the small device when installing and do not over tighten it. Attach the AABS (2) to the mounting block using the thumbscrew (3) and making sure that it is adjusted so that it is as high up (4) as possible.



3. Power on the VersaLASER. Load some scrap material of the same type you intend to process and set focus using the Focus Tool. Adjust the angle of the nozzle by loosening the thumbscrew (1), rotating the bracket, and re-tightening the thumbscrew. You can also adjust the height (2) by loosening the mounting thumbscrew, making the adjustment and re-tightening the thumbscrew. Use the Red Dot pointer as your guide to where the laser beam will strike the material.

WARNING: Since the AABS hangs downwards toward the surface of your material and the surface of the table, ensure that the motion of the Focus Carriage will not cause the AABS to mechanically interfere with your material or components of the VersaLASER otherwise serious damage may occur.

Usage

If this is the first time using the AABS, open the needle valve all the way, counter clockwise. This will result in maximum airflow. To lock the adjustment in place, rotate the round locking nut clockwise until it seats.

Load and run a job. Make sure that the CCCAU unit turns on (if purchased) or your compressed air source is operating when the job starts processing. Observe how the smoke is being pushed away. If you would like to reduce the flow or to change the angle or height of the airflow, pause the job and adjust as necessary.

Removal

Remove the height adjustment thumbscrew and detach the AABS from the mount. Re-attach the thumbscrew to the mount so that it doesn't get lost. Either detach the accessory by unscrewing the needle valve and reinstalling the plug (the same way you installed it), or by the preferred method of un-attaching the hose from the needle valve by either using a wrench to loosen the nut at the end of the hose or by simply using the cone as your wrench and turning it counter clockwise. This way, the needle valve remains attached to the Focus Carriage for the next time you install the accessory. The same needle valve is also used for the AAC accessory.

